

98. Recommended spare parts: DWK, DPK

50/60 Hz

Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: ()
	Fax number: ()

Pump information

Type		P.c.	
Model			
Hmax	m	Qmax	l/s
Tmax.	°C		
IP68	Insul.class	CosΦ	
Motor	~	Hz	P1/P2
n	min ⁻¹	Δ	V
Weight	kg	γ	V

96883812

CE EAC

GRUNDFOS

DK-8850 Bjerringbro Denmark

Made in China

Quotation made by

Company name:

Prepared by:

Phone number: ()

Fax number: ()

Date:

Quote number:

Recommended spare parts

Kit - Spare - Bulk	Recommended service parts						Product number
	1 pump		2 to 3 pumps		4 to 7 pumps		
	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	
Kit, Shaft seal	1	2	2	3	4	8	
Kit, O-ring	1	2	2	3	4	8	
Kit, Impeller	0	1	0	2	0	4	
Kit, Bearing	0	1	0	2	0	4	
Oil*	1	2	2	3	4	8	

* See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.

If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.

