

96. Recommended spare parts: DP, EF AUTO_{ADAPT}

50/60 Hz

Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: ()
	Fax number: ()

Pump information

Quotation made by

Type: _____

Model: _____

P.c. _____

IP68 _____ m

Hmax: _____ m Qmax: _____ l/s

P1: _____ kW P2: _____ kW

~ _____ A

n: _____ min⁻¹ Cosφ : _____

Weight: _____ kg Tmax. : _____ °C

~ opr.: _____ μF _____ Hz

Insul.class: _____

Made in Tatabanya. Hungary

CE 0197 GRUNDFOS DK-8850 Bjerringbro Denmark

Company name:

Prepared by:

Phone number: ()

Fax number: ()

Date:

Quote number:

Recommended spare parts

	Recommended service parts						
	1 pump		2 to 3 pumps		4 to 7 pumps		
Kit - Spare - Bulk	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	Product number
Kit, Shaft seal	1	2	2	3	4	8	
Kit, O-ring	1	2	2	3	4	8	
Kit, Impeller	0	1	0	2	0	4	
Kit, Bearing	0	1	0	2	0	4	
Kit, Dry-running sensor*	0	1	0	1	0	1	
Kit, level sensor*	0	1	0	1	0	1	
Oil**	0	1	0	1	0	1	

* Only for AUTO_{ADAPT}.

** See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.

If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.