

104. Recommended spare parts: SEG

50/60 Hz

Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: ()
	Fax number: ()

Pump information

Quotation made by

Type:			
Model:			
P.c.			
IP68	∇	m	
Hmax:	m	Qmax:	l/s
P1:	kW	P2:	kW
	~		A
n:	min ⁻¹	Cosφ :	
Weight:	kg	Tmax. :	°C
-I- opr.:	μF		Hz
Insul.class:			
Made in Tatabanya. Hungary			

98807792

CE 0197

GRUNDFOS

DK-8850 Bjerringbro Denmark

Company name:

Prepared by:

Phone number: ()

Fax number: ()

Date:

Quote number:

Recommended spare parts

	Recommended service parts						
	1 pump		2 to 3 pumps		4 to 7 pumps		
Kit - Spare - Bulk	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	2 years units per pump	5 years units per pump	Product number
Kit, Shaft seal	1	2	2	3	4	8	
Kit, O-ring	1	2	2	3	4	8	
Kit, Impeller	0	1	0	2	0	4	
Kit, Bearing	0	1	0	2	0	4	
Kit, Grinder	0	1	0	2	0	4	
Kit, Dry-running sensor*	0	1	0	1	0	1	
Kit, level sensor*	0	1	0	1	0	1	

* Only for AUTO_{ADAPT}.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.

If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.